

```
357213
1
                  Nut, Push-In (2)
2
                  Top
      3358200
                  For White Model
3
      62750
                  Spacer, Cabinet To Top (4)
                  Cabinet
5
      63424
                  For White Model
6
      62780
                 Clip, Top & Cabinet & Rear Panel (2)
8
      3356311
                  Screw & Washer, Lid Switch (2)
9
      3352629
                  Switch, Lid
13
      3351355
                  Screw, Lid Hinge Mounting (4)
15
     54584
                  Hinge, Lid (L.H.)
16
     54583
                  Hinge, Lid (R.H.)
17
     19119
                  Bumper, Lid Hinge
18
      21258
                  Bearing, Lid Hinge (2)
19
                  Lid
                 For White Model
      3361392
20
     358684
                  Strike, Lid Switch
22
     93770
                  Bumper, Lid (2)
28
     384435
                  Screw, 10-16 \times 1/2 (4)
31
      90016
                  Clip, Harness
32
      3362952
                  Dispenser, Bleach
LITERATURE AND OPTIONAL PARTS
LITERATURE PARTS
     LIT3360057 Sheet, Installation Instructions
     LIT3363548 Guide, Use and Care
     LIT3361382 Energy Guide
      LIT3946227 Label, Wiring Diagram
      LIT4313896 Manual, (Washer) Do-It-Yourself
OPTIONAL PARTS NOT INCLUDED
PAINT, TOUCH-UP (1/2oz.)
      72017
                 White
      72107
                  Almond
      72110
                  Golden Harvest
PAINT, PRESSURIZED SPRAY (13 oz.)
      350938
             Primer, Gray
      350930
                  White
      350956
                  Almond
                  Golden Harvest
      261890
PAINT, BULK (1 qt.)
      799344
               White (Uncut)
      978883
                 Almond (Uncut)
      261891
                 Golden Harvest (Uncut)
OIL
      350572
                  Oil, Gearcase (16 Oz.)
LUBRICANT
      285208
                  Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)
SEALER
                  Sealer, Gasket (.20 Fl. Oz.) (6 ml)
      285195
```


SHIPPING KIT

3348675 Shipping Kit

ACCESSORY PARTS


63580 Fabric Dispenser 89121 Stand-Pipe Kit 367031 Drain Protector 285320 Siphon Break Kit

CONTROLS AND REAR PANEL PARTS



```
Washer, Water Inlet Hose (4) (1-1/16 \times 5/8)
1
      16123
2
      3354285
                   Switch, Cycle Modifier
3
      3354858
                   Hose, Water Inlet (2)
4
      3357027
                   Nozzle-Drain Hose
5
      387402
                  Hinge, Console (2)
6
      3357978
                   Panel, Rear
7
      62747
                   Pad, Rear Panel
8
      661575
                   Hose, Drain (4'- 8")
                   Hose, Drain (9'- 9") (Not Included)
      661577
      3357090
                   Extension Drain Hose (21 Inches.) (Not Included.)
9
      3946225
                   Timer, Control (60 Hz.) (Motor Not A Service Part)
11
      90767
                   Screw 8A \times 3/8
12
      3356465
                   Switch, Water Level
13
      3360936
                   Bracket, Control
14
      3360514
                   Cord, Power
                   Strain Relief, Power Cord
15
      63848
16
                   Cap, End (L.H.)
      3358531
                   For White Model
      96160
                   Screen, Filter (2)
17
18
      3360392
                   Valve, Water Mixing
                   Screw, 10-24 \times 3/8 (2)
19
      90864
21
      370451
                   Clamp, Hose
      272846
                   (Alt.)
      353367
                   (Alt.)
                   Hose, Vacuum Break
2.2
      3357328
                   Clamp, Hose
2.3
      371503
24
      3347034
                   Break, Vacuum
                   Support, Rear Panel
25
      63290
26
      3361805
                   Hose-Corrugated Assy.
27
      356138
                   Clamp, Hose
30
      371502
                   Clamp, Hose
31
      660628
                   Clamp, Hose
      272858
                   (Alt.)
      370447
                   (Alt.)
      353097
                   (Alt.)
32
                   Hose, Pump To Tub
      62731
35
      661537
                   Switch, Water Temperature
                   Screw, Timer Mounting (10-32 \times 1) (2)
36
      96435
39
                   Panel, Console
      3363068
                   For White Model
44
                   Knob, Timer
      3364291
      3946261
45
                   Dial, Timer
                   Knob, Control
47
      3358435
49
      3353145
                   Screw, 8-18 (Panel to Top)
50
      62863
                   Screw, 10-16 \times 3/8
51
                   Cap , End (R.H.)
      3358516
                   For White Model
55
      3357011
                   Screw, 10-16 \times 1/2
58
      3357331
                   Clamp, Drain Hose
59
      3362569
                   Wiring, Harness (For Detail See Wiring Harness Parts Page)
Also See Clips.
```


AGITATOR, BASKET AND TUB PARTS



```
2
                  Screw & Washer (5-16-24 \times 1)
      358237
3
                  Clothes Mover
      3349019
4
      3350830
                  Agitator
5
                  Tub Ring & Gasket
      3360611
                  Gasket, Tub Ring
6
     3359586
7
     387868
                  Balance Ring
                  Clip, Balance Ring (8)
8
      387867
                  Cam Driven
9
      3351001
      387091
                  Dog, Agitator Clutch
10
11
      3354845
                  Clip-Agitator
12
      21366
                  Nut, Spanner
13
      3357245
                  Basket
14
      3361948
                  Filter, Plate
15
     3355921
                  Washer-Agitator
16
      63039
                  Tub
17
      389140
                  Block, Basket Drive
18
      383727
                  Gasket, Centerpost
19
      3347780
                  Hose, Pressure Switch
21
                  Hose, Bleach
      3358198
22
      3350389
                  Spacer, Thrust
23
      3354733
                  Cap, Barrier
24
      3348855
                  Seal, Inner Cap
25
      3350829
                  Agitator Assy
```


Washer

MISCELLANEOUS PARTS



```
1 3359460 Miscellaneous Parts Bag
2 16123 Washer, Inlet Hose (1-1/16 x 5/8) (4)
4 3359452 Nut, Lock (3/8-16)
5 389102 Foot, Front (2)
7 356138 Clamp, Hose
```

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS




```
388951
                  Brake & Drive Tube (Complete) (Refer to Brake & Drive Tube
1
Parts Page For Further Breakdown)
      63292
                  Washer, Spin Tube Thrust
                  Ring, Spin Tube Support
3
      62697
4
      63283
                  Ring, Retainer
5
      3946794
                  Clutch (Complete)
6
     3946793
                  Band & Lining, Clutch (Includes Illus. 7 & 8)
7
     62646
                  Cap, Clutch Spring (2)
8
      3363337
                  Spring, Clutch
9
      3360630
                  Gearcase (Complete) (Refer To Gearcase Parts Page For Further
Breakdown)
10
     3357334
                  Screw, Gearcase To Base (3)
11
     62611
                  Plate, Motor Mount To Gearcase
12
     62691
                  Grommet, Motor (4)
13
      3364003
                  Coupling, Motor & Isolation
15
                  Clip, Anti-Rattle
      3355454
16
      3357334
                  Screw,
17
      3349637
                  Retainer, Motor (2)
18
     3362089
                  Shield, Tub To Motor
19
     661600
                  Motor, Main Drive
                  Switch, Main Drive Motor
20
      62850
                  Retainer, Pump (2)
21
      62700
                  Pump (Complete)
22
      3363394
23
      3387485
                  Screw, 10-16 \times 5/8
24
     3946532
                  Shield, Motor
25
     62863
                  Screw, 10-16 \times 3/8
26
     357021
                  Capacitor
27
     357030
                  Clamp, Capacitor
```

MACHINE BASE PARTS For Model: LLR9245BQ1 (Designer White) 23 -LOWER = 16 ₋18 6 J

```
1
      343641
                  Screw, Bracket Mounting (10-16 x 1/2)
2
      64067
                  Bracket, Spring Outer (2)
3
      63907
                  Spring Suspension, (3)
                  Support & Brake, Tub
4
      3362087
5
      64065
                  Bracket, Spring Outer (L.F.)
6
      63466
                  Link, Leveling Mechanism (2)
7
      62597
                  Spring, Leveling Mechanism
                  Pin, Knurled
8
      62837
                  Foot, Rear (2)
      62596
9
13
      3347047
                  Bearing, Centerpost (2)
14
      357409
                  Seal, Centerpost (3)
15
      388492
                  Spring, Counterweight
16
      62568
                  Pad, Plate
17
      3946509
                  Plate, Suspension (Includes Illus. 16)
18
      3363660
                  Pad, Base
19
      3946512
                  Base Assembly (Includes Illus, 6, 7, 8, 9, 18 & 26)
21
      3359452
                  Nut, Lock (3/8-16)
      389102
22
                  Foot, Front (2)
23
      356934
                  Seal, Centerpost (2)
                  Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
24
      285203
25
      63134
                  Ring, Sound Deadening
26
      63806
                  Retainer, Suspension Spring
```

WIRING HARNESS PARTS

For Model: LLR9245BQ1 (Designer White)



9


WH2D

```
Clip, Harness
1
     3349557
2
                 Clip, Harness
     388498
3
      3347812
                 Clip, Harness
4
     3352501
                 Clip, Harness
5
     90016
                 Clip, Harness
6
     3390496
                 Clip, Harness
7
     389379
                 Retainer, (Suds Models)
8
     352090
                  Timer, Block Disconnect (White)
                  Timer, Block Disconnect (Black)
9
     352089
10
     62889
                 Receptacle, Terminal (3-Way) (Lid Switch) (Use Term. 94613 Or
94614.)
11
     353424
                  Plug, Terminal (3-Way) (Power Cord) (Use Term.94613)
12
     62505
                  Block, Disconnect (Motor 2 Speed) (Use Term.352088)
13
     3348075
                  Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)
14
     3347243
                  Block, Disconnect (Use Term. 352088)
                  Protector
15
     63523
16
     717252
                  Connector (2-Way) (Use Term.94614)
17
     387566
                  Plug, Terminal (4-Way) (Power Cord) (Use M3 Screws)
18
     3352944
                 Clip, Harness
19
     3390423
                  Block, Disconnect (12-Way) (Timer) (Use Term. 94613)
20
     3347730
                  Receptacle (6-Way) (Use Term. 94613)
                  Plug, Terminal (12-Way) (Use Term. 94613 Or 94614.)
     388818
21
                  Timer, Block Disconnect (Black) (Amp) (Use Term. 3369365)
22
      3369366
23
     3349494
                  Connector, Etc
2.4
     60687
                  Connector, Relay (Use Term. 308569 Or 338664.)
25
     3407125
                  E.T.C. Control
```

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

BRAKE AND DRIVE TUBE PARTS

For Model: LLR9245BQ1




```
1
     388951
                Brake And Drive Tube (Complete)
                 Ring, Thrust
2
     62658
                 Seal, Oil
3
     91939
                 Seal, Drive Tube
4
     356427
5
     356937
                 Spacer, Drive Tube
6
     64027
                 Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7
     64035
                 Ring, Retaining
                 Brake Shoe
8
     64232
     62703
                 "T" Bearing, Spin Tube
9
10
     62648
                 Cap, Brake Spring (2)
     62647
11
                 Spring, Brake
     62909
12
                 Sleeve, Brake Spring
13
     63023
                 Cam, Brake Release
14
     63022
                 Sleeve, Cam
15
     64194
                 Driver, Brake Cam
16
     90368
                 Ring, Retaining
```

FOLLOWING PARTS NOT ILLUSTRATED

285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

GEARCASE PARTS

For Model: LLR9245BQ1 (Designer White)





GC-215C

```
1
     3360630
                 Gearcase (Complete)
2
      285202
                  Cover, Gearcase
3
      3349985
                  Seal, Gearcase Cover
                  Sealer, Gasket (.20 Fl. Oz.) (6 ml)
4
     285195
5
     63320
                  Pinion, Spin (Includes Illus. 25)
6
     356427
                  Seal, Spin Pinion
7
     389387
                  Shaft, Agitator (Complete)
     90369
8
                 Ring, Retaining (2)
     62677
                  Retainer, Spring
9
10
     62676
                  Spring, Agitate
11
     63273
                  Gear, Agitate (Includes 15 and 29)
12
     62619
                  Washer, Agitate Gear
13
     62580
                  Cam Follower (Includes 14)
14
     62581
                  Cam, Agitate (Includes 13)
15
     285509
                  Shaft, Agitator (Includes 11 and 29)
16
                  Washer, Cam Thrust
     62618
17
     16018
                  Bearing, Thrust
18
     85529
                 Ball, Bearing
19
     389230
                  Bottom and Pinion, Gearcase
21
     285352
                  Seal, Thrust Plug
                  Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
22
     3351614
                  Ring, Retaining
23
     3362552
                 Washer Kit, Thrust
24
     285735
25
     62570
                  Gear, Spin
     388253
26
                 Neutral Assembly
27
     3349296
                 Rack, Connecting
28
     62621
                  Actuator, Shift
29
     388815
                  Washer, Intermediate
```

WATER SYSTEM PARTS

For Model: LLR9245BQ1 (Designer White)





WS400

1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)